TABLE OF CONTENTS

Index

1	Before driving	1-4.	Opening and closing the windows and retractable hardtop
			Power windows 53
1-1.	Key information		Retractable hardtop 56
	Keys20	1-5.	Refueling
1-2.	Opening, closing and locking the doors and trunk		Removing the fuel tank cap 60
	Wireless remote control 22	1-6.	Theft deterrent system
	Doors25		Engine immobilizer system 64
	Trunk29		Alarm
1-3.	Adjustable components		Theft prevention labels (U.S.A. Only)68
	(seats, mirrors, steering wheel)		
	Front seats	1-7.	Safety information
	Driving position memory		Correct driving posture 69
	system35		SRS airbags 71
	Head restraints38		Front passenger occupant
	Seat belts 40		classification system82
	Steering wheel		Child restraint system 87
	Inside rear view mirror49		Installing child restraints 91
	Outside rear view mirrors 50		

2-3. Operating the headlight When driving 2-1. Driving procedures Driving the vehicle......104 Engine (ignition) switch 113 Automatic transmission...... 116 Turn signal lever 120 Parking brake 121 Horn...... 122 2-2. Instrument cluster and information display Gauges and meters 123 Indicators and warning lights......125 Trip information display...... 128

	and windshield wipers	
	Headlight switch 129	
	Fog light switch 132	1
	Windshield wipers and washer133	1
	Headlight cleaner switch 136	
2-4.	Using other driving systems	2
	Cruise control 137	
	Driver assist systems 140	
		3
2-5.	Driving information	
	Cargo & luggage 145	
	Vehicle load limits 148	
	Winter driving tips 149	4
	Trailer towing	

Dinghy towing 154

TABLE OF CONTENTS

Index

3 Interior features		3-5.	Other interior features	
			Sun visors	190
			Clock	191
3-1.	Using the air conditioning system		Ashtray	192
	and defogger		Cigarette lighter	193
	Automatic air conditioning		Power outlet	194
	control 156		Seat heaters	195
	Rear window defogger161		Floor mats	197
			Trunk features	198
3-2.	Using the audio system		Garage door opener	200
	Audio system 162			
	Opening the audio door 164	4 Maintenance and care		
	Using the radio165		1 Maintenance and care	
	Using the cassette player 169			
	Using the CD changer 172	4-1.	Maintenance and care	
	Optimal use of the audio system 178		Cleaning and protecting the vehicle exterior	208
	Using the steering switches 180		Cleaning and protecting the vehicle interior	21
3-3.	Turning on interior lights			
	Interior lights list183	4-2.	Maintenance	
			Maintenance requirements	214
3-4.	Storage		General maintenance	216
	Storage features 185		Emission inspection and maintenance (I/M) programs	219

4

4-3.	Do-it-yourself maintenance	5-2.	Steps to take in an emergency	
	Do-it-yourself service precautions		If the warning light turns on	
	Hood		If you have a flat tire (Vehicles with run-flat tires)	1
	Tires 242 Tire inflation pressure 251 Wheels 256		If you have a flat tire (Vehicles with standard tires)	2
	Air conditioning filter		If the shift lever cannot be shifted from P	3
	Cartridge fuses 271 Headlight aim 273 Light bulbs 275		a discharged battery	4
5	When trouble arises		If the retractable hardtop does not close	5
5-1.	Essential information Emergency flashers	6	Vehicle specifications	
	If your vehicle needs to be towed	6-1.	Specifications	6
	If you think something is wrong		Maintenance data (fuel, oil level, etc.)	
	Fuel pump shut off system 289 Event data recorder		Fuel information	7
		6-2.	Owner's customize Customizable features	

TABLE OF CONTENTS

Index

7 For owners

Index

ı